

TO LUBRICATE PIVOT PIN-RECOMMENDED EVERY 2-3 STRING CHANGES  
(WITH STRING REMOVED)

1. FIRST UNHOOK SPRING FROM SCREW
2. CAREFULLY LIFT PULLER UNTIL PIN IS FREE OF HOLE IN HANDLE BRACKET
3. CLEAN PIN WITH PAPER TISSUE OR TOWEL
4. CLEAN RECESS WITH Q-TIP
5. ADD ONE DROP OF LIGHT OIL TO PIN
6. CAREFULLY REPLACE PULLER AND RE-ATTACH SPRING TO SCREW
7. WIPE ANY OIL FROM UNIT AFTER REASSEMBLY

DON'T LOSE OR FORGET WASHER

